

## Shear Blade Specifications

Shear Head	Shear Housing	Center Blade	Side Knife	Spacer Bushing	Cap Screw	Knurled Insert	Eccentric Bearing
40-20	40-23	40-21	60-22L 60-22R	40-27 60-27	92-28	92-31	40-24
41-20	40-23	41-21	41-22 70-05	40-27 60-27	92-28	92-31	41-24
42-20	42-23	40-21	60-22L 60-22R	42-27 60-27	92-28	92-31	40-24
60-20	60-23	60-21	60-22L 60-22R	60-27 (2)	60-28	60-31	60-24
70-20	60-23	70-21	70-22 70-05	80-27 60-27	60-28	60-31	60-24
80-20	60-23	80-21	80-22 70-05	80-27 60-27	60-28	60-31	60-24
90-20	60-23	90-21	90-22 70-05	60-27 (2)	60-28	60-31	60-24
92-20	42-23	92-21	92-22 (2)	92-27-2B 92-27-1	92-28	92-31	41-24
93-20	40-23	92-21	92-22 (2)	92-27-2B 92-27-1	92-28	92-31	41-24
94-20	42-23	95-21	92-22 (2)	92-27-2B 92-27-1	92-28	92-31	41-24
95-20	40-23	95-21	92-22 (2)	92-27-2B 92-27-1	92-28	92-31	41-24
46-20	42-23	46-21	46-22  46-05		92-28	92-31	

## Shear Blade Kit Specifications

Kit Part Number	Tool Used With	Center Blade	Side Knife	Spacer Bushing	Eccentric Bearing	Washer	Cap Screw
Kit #101	Any 18 gauge shear	60-21 (2)	60-22L 60-22R	60-27	60-24	60-25	60-28 (3)
Kit #102	Any 18 gauge shear	60-21	60-22L 60-22R	60-27			
Kit #106	Any 14 or 16 gauge shear	40-21	60-22L 60-22R				
Kit #109	Any ½" fiber-cement shear	90-21	90-22 (2)				
Kit #115	Any 5/8" fiber-cement shear	95-21	92-22 (2)				
Kit #146L	Any profile shear left cutting	46-21L	46-22L  46-05 Side spacer				
Kit #146R	Any profile shear right cutting	46-21R	46-22R  46-05 Side spacer				